


Instruction Manual

Thank you for purchasing OS product.

S-R2/Wall Switch



Index

Safety Precautions	2~3
Accessories	4
Cautions in handling	4
Setting	5
Connection diagram	5
How to use	6
Change of projection position	6~7
FAQ	7~8

■ Please kindly read this instruction manual carefully and use the product properly. This manual should be kept for future reference.

Safety Precautions

Please strictly comply with the following for safety

This instruction manual is intended to prevent any danger to the user and the third parties, or any damage to the property. The following indicators are to remind users to strictly observe the instructions.

Throughout our explanation, the possible damage which may be caused by any negligence or disregard of the safety precaution is classified to different levels according to the severity.



WARNING

This icon warns that it may cause death or casualty if not following the instruction closely.



CAUTION

This icon indicates that it may cause injury or damage to the property.

For the precautions we recommend users to notice, we explain by using the following different categories (The following are just examples).



This icon suggests that the action is strictly prohibited.



This icon suggests that this is the necessary procedure to follow.



WARNING



Do not alter the design or dismantle.

The continuous use may cause a fire and an electric shock.
Stop using it, and consult with the dealer or distributor.



Do not close a source of heat.



CAUTION



Do not damage the terminal box cable.

Don't damage, torture, twist, pull hard and bundle the cable. Do not bring close to the high temperature section or put a heavy thing onto it.
It may cause major failures.



Do not operate the IR receiver plug with a wet hand.

It may cause major failures.



Do not operate the IR receiver plug with a wet hand.

It may cause major failures.

 **CAUTION**



Make sure the terminal box plug is inserted tightly.
It may cause major failures.



Pull out the plug, when smoke, heat, smell or strange noise happens.
It may cause major failures.



Make sure the power is off when connecting to the screen.
It may cause major failures.



Make sure the wiring is firmly fixed by pressure.
It may casue malfunctions.




Do not expose the wick lines at the terminal box.
It may cause major failures.


OS Screen would not be responsible for damage caused by improper installation or natural disaster factors.

Accessories

Please confirm if every accessories are ready. If anything is missing, please contact the dealer or distributor.



Wall Switch ×1



Cable length 1m

Relay box ×1

※ Specifications and design are subject to change without notice.

Cautions in handling

- Please comply with the following cautions carefully, when you use the product..
- Do not use in the rain and water because it is not waterproof.
- When it is dirty, remove the dust with the soft dry cloth.
- Never use chemicals such as benzene, thinner etc. for cleaning.

Setting




CAUTION

Make sure the power is off when you connect it to the screen. It may destroy the product.

Plug in the relay box plug tightly. If not, it may cause mal-functioning.


1. Connect the modular plug of the relay box to the modular jack



2. Please refer to the following connection diagram for connecting the relay box to the wall box.

※The cable between the wall switch to the relay box are not supplied. Please prepare for example: Less than $0.75\text{mm}^2 \times 4\text{C} \times 1$

Connection Diagram



How to use

■ Storing the screen


When the screen is deployed, push the **UP** button of the wall switch.
The screen is rolled up and stored, and it stops automatically.

■ Stopping the screen

Please push the **STOP** button whenever you want to stop the operation.

■ Deploying the screen

Please confirm the screen is stored, and push the **DOWN** button of the remote controller. The screen is deployed to a prescribed projection position, and it stops automatically.



CAUTION Pull out the power plug, when the screen is not used for long.
The leak may cause a fire.

Change of projection position

- The projection position can be changed as desired.



● To lift up the projection position

① Stop at the desired position.

Use **UP** & **DOWN** buttons and push **STOP** button at the desired position.

② Memorizing the position

1. At the desired position, push **STOP** button for 5-6 seconds, and then push **DOWN** button within 2 seconds.
2. Upon receiving the command, the screen moves up approx. 10cm, and then stops at the preset position.




To lift down the projection position


Deploy the screen

Push **DOWN** button for 5-6 seconds and the screen starts to come down from the preset position.

Push **STOP** button.





Push DOWN for some time and then, push STOP



Stop at the desired position


Use **UP** & **DOWN** buttons and push **STOP** button at the desired position.




Memorizing the position

1. At the desired position, push **STOP** button for 5-6 seconds, and then push **DOWN** button within 2 seconds

2. Upon receiving the command, the screen moves up approx. 10cm, and then stops at the preset position.



Push STOP for some time and then push DOWN



NOTICE If the **DOWN** button is pushed for some time and left as it is, the screen comes to the factory default position, and stops. The screen cannot be lower than this position.

FAQ

In case of malfunctions, please refer to the following table before asking for the repair work. Make sure the power plug is disconnected before checking. If the problem is not solved, please consult with the dealer or the distributor.

Symptom	Check	Remedy
The screen does not operate	Is power plug fixed to the mains correctly?	Fix the plug tightly.
	Is the connection between the wall switch and the relay box same as the connection diagram?	Connect according to the diagram.

The screen does not operate	Is the heat prevention circuitry on?	Cool off the motor and operate again after 10-20 minutes. After cooling off, the stop position might be changed. Reset the stored position, using UP operation.
	Is there a power failure during operation?	If the power fails during operation, UP or DOWN operation restores the screen to reset.
No adjustments on the lift down position	Confirm the procedures explained in the manual.	Store up the screen, and wait more than 1 second for re-setting.

OSI CO., LTD.

Room 1605, 16/F, Seaview Centre, 139 Hoi Bun Road,
Kwun Tong, Kowloon, Hong Kong

PHONE : +852-3580-0087 FAX : +852-2367-4300

E-mail : info-hk@os-worldwide.com

U R L : <http://www.os-worldwide.com>